



# Quick Start Guide for SunStat™ Programmable Controls

## 1. Turn SunStat On




## 2. Set Time & Day



- Press Day/Time and hold for 1 second (hour should blink).
- Press Up or Down arrow to adjust time.
- Press Day/Time (minutes should blink).
- Press Up or Down to adjust minutes.
- Press Day/Time button (day should blink).
- Press Up or Down to adjust day.
- Press Hold/Return to exit.

## 3. Choose Pre-Set Schedule



- Press and hold the Program button for 1 second.
- Press Up or Down arrows to cycle through each of the presets (U1\*, P1, P2, P3, and P4 - see below).
- Press Hold/Return, or wait 15 seconds to select schedule.
- Thermostat will now display selected schedule at bottom right of screen.

### P1 (Early Riser)

Cycle	1	2	3	4
Mon-Fri	5:00 am 82 F	7:00 am 74 F	5:00 pm 82 F	10:00 pm 74 F
Weekend	5:00 am 82 F	9:00 am 74 F	5:00 pm 82 F	10:00 pm 74 F

### P2 (Longer Day)

Cycle	1	2	3	4
Mon-Fri	5:00 am 82 F	8:00 am 74 F	6:00 pm 82 F	11:00 pm 74 F
Weekend	6:00 am 82 F	9:00 am 74 F	5:00 pm 82 F	11:00 pm 74 F

### P3 (At home during the day)


Cycle	1	2	3	4
Mon-Fri	6:00 am 82 F	8:00 am 79 F	6:00 pm 82 F	10:00 pm 75 F
Weekend	6:00 am 82 F	9:00 am 79 F	6:00 pm 82 F	10:00 pm 75 F

### P4 (Take the chill off)

Cycle	1	2	3	4
Mon-Fri	6:00 am 75 F	9:00 am 70 F	6:00 pm 75 F	10:00 pm 70 F
Weekend	7:00 am 75 F	10:00 am 70 F	6:00 pm 75 F	10:00 pm 70 F

- \* U1 user schedule is customizable. Please see full manual for details.

## OPTIONAL



### To set a temperature manually, overriding the programming

- Adjust temperature set point with Up or Down arrows.
- Press and hold the Hold/Return button for 2 seconds until "HOLD" is displayed.
- The set point temperature will override the pre-set schedule. To go back to a pre-set schedule, see Step 3.

If you need the full instructions, please visit [WattsRadiant.com](http://WattsRadiant.com) and find the HeatWeave Controls literature under the Support tab.

